

Changing the Speed Unit from KM/H to MPH

“ One parameter — P02 — and the two settings people change by mistake instead.

Applies to: D-series

<https://www.youtube.com/embed/aNRi90Jun4k?rel=0>

Change Speed Unit from KM/H to MPH — if the player does not load, [open the video on YouTube](#).

The setting

P02 controls the speed unit:

Value	Unit
0	KM/H
1	MPH

Steps

1. **Power on** the bike and open the parameter menu (the display's settings entry).
2. **Navigate to P02.**
3. **Change the value** — 0 for KM/H, 1 for MPH.
4. **Save and exit** the menu properly.
5. **Power cycle** — off, then on.
6. **Confirm** the speedo now reads in the unit you chose.

Watch out for

The two adjacent settings are **not** the speed unit, and changing them causes real problems:

- **P06 (wheel diameter)** — changes speedo *accuracy*. Set it wrong and the displayed speed is wrong in either unit.
- **P07 (speed signal magnets)** — changes the speedo *calibration*. Wrong value = wrong speed reading.

If your speedo is reading a plausible but **incorrect** number, the unit is probably fine and P06/P07 is the real problem. See the [P-Setting Guide](#).

Related

- [P-Setting Guide](#)
 - [How to Limit Speed](#)
 - [Display & Settings](#)
 - [Tutorials Index](#)
-

Revision #8

Created 2026-09-22 02:00:24 UTC by Cemoto

Updated 2026-09-22 04:52:03 UTC by Cemoto